



PLEASE NOTE THAT THE WAY THE KIT IS PACKED DOES NOT NECESSARILY REPRESENT THE WAY OF MOUNTING TO THE $${\rm Bike}$$

Fitting Instructions for CP0003BL Crash Protectors Aprilia Mille / RSVR Lowers

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – the rubber washers should be thrown away!

Nearside or Left hand side Lower Protectors

- Undo Nearside rear engine bolt (15mm ring spanner required inside)
- Remove bolt
- Offer R & G bobbin up to bike
- Slide R & G bar through centre of bobbin and into engine, slide M10 washer and nyloc (finger tight) on exposed end of bar. Ensure short thread is to the outside of the bike.
- Slide bar through as far as it will go
- Slide M10 washer on bar
- Screw nyloc and tighten whole assembly. Tighten bolt until you feel some compression from inside the protector. Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Do not overtighten as damage can occur to the bike. Do not exceed 40nm of torque.
- Repeat for Offside (right hand side) as you sit on the bike

Note: Longer of two bars and smaller necked bobbin go on the left hand side lower

Due to the risk of cross-threading of bolts etc; we always recommend that our products be fitted by one of our official dealers or a qualified mechanic.



CONSUMER INSERT

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes.

Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products.

On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect.

Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned.

These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected)

Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor.

Goods must be in re-sellable condition, in the opinion of R&G Racing.

All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase).

The customer must pay any and all carriage charges.

No returns of discontinued products, unless within 14 days of purchase.

This policy does not affect your statutory rights and does not refer to faulty goods.



France

$\underline{\text{La presentation des pieces R\&G dans L'emballage n'est pas toujours identique au sens de montage.}$

CP0003BL

Aprilia Mille / RSVR position basse

Merci de noter que dans le cas où les protections sont assemblées avec une bague en caoutchouc, merci de bien vouloir le retirer lors du montage des pièces sur la moto.

GAUCHE:

- Desserrer l'écrou de fixation moteur arrière (utiliser une clé à douille de 15mm)
- Enlever la vis de fixation moteur.
- Placer le tampon R&G sur la moto
- Prendre la barre R & G, glisser une rondelle M10 et un écrou autobloquant (serrage à la main) sur le filetage de la barre. Le filetage le plus court vers l'extérieur de la moto.
- Glisser la barre à travers le tampon,
- Mettre une rondelle M10
- Visser l'écrou autobloquant sur la barre et serrer l'ensemble.
- Serrer la vis jusqu'a ce que vous sentiez la compression à l'intérieur du tampon, ne pas trop serrer. Couple de serrage Maxi 40nm.
- Refaire les mêmes opérations pour le côté Droit.

Note: la barre et le tampon les plus longs se placent côté gauche de la moto.

NOUS VOUS CONSEILLONS DE FAIRE MONTER LE KIT TAMPON R&G PAR VOTRE REVENDEUR, LUI SEUL SERA QUALIFIE POUR MONTER CES PIECES.