

## Install Guide for **GPX-Y03** Harness Kit

### For use with the following YAMAHA motorcycles:

YZF-R125 (2008-2010)

*Disclaimer: Do not attempt to install the product if you don't have basic mechanical skills. HealTech Electronics Ltd. and its distributors shall not be liable for any loss or damage caused by improper installation. If in doubt, please consult with your dealer.*

**1. Remove** the seat, raise and support the fuel tank.

**2. Locate the Speed Sensor coupler.**

The speed sensor is at the front wheel. Trace the cable until you find the 3-pole sensor coupler. The 3-pole speed sensor coupler (semi-transparent) is below the instrument cluster.

If in doubt, check the bike's Service Manual or ask your dealer for the location of the Speed Sensor coupler.

Confirmation:

Separate the Speed Sensor coupler (you might need to use a small flathead screwdriver to get the coupler apart). Rotate the front wheel while ignition is on. The speedometer should indicate 0. If so, turn the ignition off and proceed to the next step. Otherwise, if the speedometer registers a speed other than 0, you have not disconnected the correct coupler and need to look again.

**3. After separating the Speed Sensor coupler, plug in** both the male and female 3-pole GIpro harness connectors. Make sure the connectors are fully seated.

*If you have a **SpeedoHealer** installed, you have to connect the plugs in-line in the following order:*

*Speed sensor female plug → GIpro → SH → bike male plug*

4. Find the **2-pole** plug of the **AC magneto** (Crankshaft position sensor/Pickup coil). It has two wires coming from the crankcase: one is **Red**, the other is usually White.
5. Peel off the black sleeve (tape) near the 2-pole plug, leaving about 3 cm (1.2") of the **Red (Solid Red)** wire exposed.
6. Connect the Gipro **Black/Green** wire to the **Red** AC magneto wire, using the **Red wire tap** connector supplied.

*Usage: Place the unstripped run wire (Red) inside the run channel. Close the side cover until latched. Cut off the excess length, then insert the unstripped tap wire (Black/Green) completely and check its position. Insert the blade (u-contact) and press down by finger pressure. Then, fully depress the u-contact with pliers. Close the hinged top cover until latched.*

7. Connect the Gipro **Red wire** to a **switched +12V power** lead, e.g. to the hot wire of the front parking light, or at the Fusebox.

We recommend to make a temporary connection for the red wire (*e.g. by using a thin needle*) and see if the display turns on and off with the Ignition Key. Then cut off the excess length from the red wire and use the second **Red wire tap** connector supplied to make the connection.

8. Connect the 4-pole Gipro harness connector to the Gipro display connector.

9. Check whether everything is installed and working properly:

- **Select Neutral and turn ignition On** →

The Gipro display should count from **6** to **1**, then "**L**" flashes slowly.  
*(If not, the display is not receiving power and/or ground. Check the connections at the speed sensor connector and at the red wire.)*

- **Spin the front wheel** → the display should indicate a rolling wheel.

*(If not, the display is not receiving the speed signal. Check the connection at the speed sensor connector.)*

- **Start the engine** → "**L**" should flash **faster** for a few seconds.

*(If not, the display is not receiving the RPM signal. Check the wire tap.)*

Turn the ignition Off. If the tests still fail, disconnect the 3-pole and 4-pole connectors and check whether the connector pins are bent or pushed out of position. Spray some WD40 into the plugs.

10. Peel off the green plastic from the back of the unit, and mount the display.
11. Neatly route the Gipro harness from the 3-pole plugs to the mounting location, preferably along the frame.  
Do not bend the harness near the 4-pole connectors.  
Do not route the harness very close to the exhaust pipe or cylinder head.
12. Use black tape to secure and isolate the 4-pole connectors. To minimize cable stress, use the supplied cable ties to fasten the unit and harness to other cables.